

# MotoComp

Motorcycle Parts & Accessories

mcomp@mweb.co.za  
www.motocomp.co.za

073 750 9697

po box 59 pennington 4184  
fax 086 684 1544

## HT Coils (See Page 3 for coil data & following pages for applications)

Part No	Make	Model
HT2	Various	55mm hole spacing Twin output CDI coil. Ideal for twin spark plug cylinder heads.
HT3	Various	HT / CDI Coil Yamaha XT600, XR500R, XL500R, XL500S, XL600R
HT4	Various	HT / CDI Yamaha XT600, XR500R, XL500R, XL500S, XL600R
HT5	CDI Coil	
HT11	HT Coil	12v HT Coil (NOT CDI)
HT12	HT Coil	12v HT Coil (NOT CDI)
HT13	Various	Suzuki & Yamaha 80mm hole spacing, 2 terminals
HT14	Various	Fits Ducati & Honda bikes 80mm hole spacing, single lead, 2 terminals

<b>HT15</b>		<b>Various</b>	6v coil for British, MZ & early Japanese
<b>HT16</b>		<b>Various</b>	12v coil for British, MZ & early Japanese
<b>HT20</b>		<b>Yamaha</b>	RD250 RD350
<b>HT55</b>		<b>Various</b>	Range of MX & ATV bikes
<b>HT80</b>		<b>Various</b>	Range of MX & ATV bikes
<b>HT90</b>		<b>Suzuki</b>	Suzuki GSX & GSXR bikes
<b>HT102</b>		<b>Various</b>	Honda CG650/750/900, CBX1000, Kawasaki Z1000, Z1100
<b>HTCDI</b>		<b>Various</b>	Combined HT & CDI coil
<b>HTCDI-2</b>		<b>Various</b>	Combined HT & CDI coil
<b>HTCDI-3</b>		<b>Various</b>	Combined HT & CDI coil
<b>HTCDI-6</b>	No image available	<b>Various</b>	Combined HT & CDI coil

### HT-Coil Information

HT Coil	Primary (ohms)	Secondary (ohms)	Hole Spacing	Terminals
HT2	0.6	30000	55mm	2
HT3	0.3	2850	1 hole	2
HT4	0.6	2860	1 hole	2
HT5	0.6	2610	No hole	2
HT12	3	11790	80mm	2
HT13	1.6	11080	80mm	2
HT14	2.3	12900	80mm	2
HT15 (6v)	2.1	8770	No hole	2
HT16 (12v)	5.5	8790	No hole	2
HT20	4.4	9380	Bolts - 55mm	2
HT55	0.6	5430	55mm	1
HT80	0.5	5410	80mm	1
HT90	2.2	12500	90mm	2
HT102	2.2	12330	102mm	2

## HTCDI

<b>Honda</b>	CR125 (1981-1983), CR250 (1981-1983),
<b>Kawasaki</b>	KX125 (1980-1986), KDX175 (1980-1982), KDX200 (1983-1988),
<b>Suzuki</b>	LT80, RM100 (1980 on), LT125, LT160, RL250, RM400 (All), RM500 (All),
<b>Yamaha</b>	YZ80 (1979-1981), DT125, DT125L Clearly, YZ125 (1977-1986), YZ250 (1976-1984),
<b>KTM</b>	65SX (up to 2002), 85SX (up to 2002),

## HT03

<b>Honda</b>	XL500S (1979-1981), XR500R (1979-1985), XL600R (1983-1987),
<b>Yamaha</b>	XT600 (electric start) (1984-1990), XT600 (electric start) (1995-2000),

## HT04

<b>Honda</b>	XL500S (1979-1981), XR500R (1979-1985), XL600R (1983-1987)
--------------	--

## HT20

<b>Yamaha</b>	RD250/A/B, RD250DX (1975-1979), YDS7 (250cc), RD350/A/B, YR350/YR5 (1985-1991), RD400DX (1979),
---------------	--

## HT55

<b>Honda:</b>	CR60 (1983-1984), CR80 (1985-2002), CR85 (1985-2004), CR85 (2005-2008), TRX90, ATC110, CR125 (1984-1985), CR125 (1986-1989), CR125 (1990-1996), CR125 (1997-1998), CR125 (1998-1999), CR125 (2000-2001), ATC185 (1980-1986), ATC200X (1983-1986), TRX200, ATC250 (1984-1987), ATC250ES F-J (1985-1988), ATC250R (1981-1984), CR250 (1984-1985), CR250 (1986-1988), CR250 (1989-1992), CR250 (1993-1996), CR250 (1997-1998), CR250 (1999-2001), CR250R (2004-2008), TRX250 (1985-1986), XL250S (1978-1981), XR250L (1986-1995), XR250R (1986-1995), TRX300, TRX300EX, TRX350, XR350R (1983-1985), FL400R Pilot (1989-1990), TRX400EX (1999-2004), XR400R (1996-2005), CRF450 (2001-2003), CRF450 (2004), CRF450 (2005), TRX450EX (1999-2004), CR500 (1985-1986), CR500 (1986-1987), CR500 (1987-2002), XR600R (1985-1991), XR650R (2000-2007),
---------------	---

<b>Kawasaki</b>	KX60 (1980-1996), KX60 (1997-2000), KX65 (2000-2005), KX65 (2006-2009), KX80 (1981-1989), KX80 (1990-1991), KX80 (1992-2000), KX85 (2003-2010), KX100 (1981-1988), KX100 (1989-1991), KX100 (1992-2000), KLF110 Mojave (1987-1988), KDX125 (1981-1988), KX125 (1987-1988), KX125 (1989-1991), KX125 (1992-1994), KX125 (1995-1997), KX125 (1998-2000), KX125 (2001-2002), KX125 (2003-2008), KLF185 Bayou (1985-1988), KDX200 (1989-2006), KLT200 (1981-1984), KLF220 Bayou (1988-2002), KDX250 (1978-1988), KLT250 (1982-1985), KX250 (1981-1988), KX250 (1989-1991), KX250 (1992-1997), KX250 (1998), KX250 (1999-2004), KX250 (2005-2008), KEF300 (1995-2004), KLF300 Bayou (1986-2004), KLX300 (1996-2001), KX400 (1974-1976), KX500 (1983-1985), KX500 (1986-1989), KX500 (1990-2004),
-----------------	--

<b>Suzuki</b>	RM80 (1980 on), RM85 (2000-2010), RM125 (1981-1988), RM125 (1994-1997), RM125 (1998-2003), RM125 (2004), RM125 (2005-2010), LT230, LT-F4WD, RM250 (1981-1985), RM250 (1986-1993), RM250 (1994-1997), RM250 (1998), RM250 (1999-2001), RM250 (2002-2004), RM250 (2005-2006), RM250 (2007-2010),
---------------	--

<b>Yamaha</b>	PW50 (All), Moto 4 80cc, YFM225, YFB250 (1989-1998), YFM350 Warrior (2002-2004), YFZ350 Banshee (1997-2006), YFM600, YFM660 Raptor (2000-2001), YFM660 Raptor (2002-2007),
---------------	---

<b>Gas Gas</b>	EC200 (1997-2000), EC200 (2000 on), XC200 (1997 on), EC250 (1997-2000), EC250 (2000-2004), MC250 (1997-2004), XC250 (1997-2004), EC300 (1997-1999), EC300 (2000-2004), XC300 (1997-2004),
----------------	--

<b>Husqvarna</b>	125 (2005-2010), 250 (2001), 250 (2003-2004), 250 (2004 on), 250F (2004), 250F (2005-2010), TE410 (2004 on), 450F (2004), 450F (2005-2007), 610F (2000 on),
------------------	--

<b>KTM</b>	125SX (2000-2005), 125SX (2006-2010), 200SX, 250SX SEM Digitech (1985-1992), 400SX, 450SX (2000-2005), 520SX (2004-2005), 525SX (2004-2005),
------------	---

## HT80

<b>Honda</b>	CR85 (1985-2004), CR85 (2005-2008), TRX90, ATC110, CR125 (1984-1985), CR125 (1990-1996), CR125 (1997-1998), ATC185 (1980-1986), ATC200X (1983-1986), TRX200, ATC250 (1984-1987), ATC250ES F-J (1985-1988), ATC250R (1981-1984), CR250 (1984-1985), CR250 (1986-1988), CR250 (1989-1992), CR250 (1993-1996), TRX250 (1985-1986), XR250L (1986-1995), XR250R (1986-1995), TRX300, TRX300EX, TRX350, XR350R (1983-1985), FL400R Pilot (1989-1990), TRX400EX (1999-2004), XR400R (1996-2005), CRF450 (2001-2003), CRF450 (2004), CRF450 (2005), TRX450EX (1999-2004), CR500 (1986-1987), CR500 (1987-2002), XR600R (1985-1991), XR650R (2000-2007)
<b>Kawasaki</b>	KX60 (1980-1996), KX60 (1997-2000), KX65 (2000-2005), KX65 (2006-2009), KX80 (1981-1989), KX80 (1990-1991), KX80 (1992-2000), KX100 (1981-1988), KX100 (1989-1991), KX100 (1992-2000), KLF110 Mojave (1987-1988), KDX125 (1981-1988), KX125 (1987-1988), KX125 (1989-1991), KX125 (1992-1994), KX125 (1995-1997), KX125 (1998-2000), KX125 (2001-2002), KX125 (2003-2008), KLF185 Bayou (1985-1988), KDX200 (1989-2006), KLT200 (1981-1984), KLF220 Bayou (1988-2002), KDX250 (1978-1988), KLT250 (1982-1985), KX250 (1981-1988), KX250 (1989-1991), KX250 (1992-1997), KX250 (1998), KX250 (1999-2004), KX250 (2005-2008), KEF300 (1995-2004), KLF300 Bayou (1986-2004), KLX300 (1996-2001), KX400 (1974-1976), KX500 (1983-1985), KX500 (1986-1989), KX500 (1990-2004)
<b>Suzuki</b>	RM125 (1989-1993), LT230, LT-F4WD, RM250 (1986-1993),

<b>Yamaha</b>	Moto 4 80cc, PW80 (All), YZ80 (1982-1992), YZ85 (2002-2010), YZ125 (1987-1989), YZ125 (1990-1991), YZ125 (1992-1995), YZ125 (1996-1999), YZ125 (2000-2001), YZ125 (2002-2004), YZ125 (2005-2010), YZ144 (2005-2010), DT175, IT200 (All), YFM225, WR250 (1990-1995), YFB250 (1989-1998), YZ250 (1985-1987), YZ250 (1988), YZ250 (1989-1990), YZ250 (1991-1995), YZ250 (1996-1999), YZ250 (2000-2002), YFM350 Warrior (2002-2004), YFZ350 Banshee (1997-2006), YZ400F (1997-1999), YZ426F (2000-2002), YZ465 (All), YZ490 (All), XT500 (kickstart), XT550 (kickstart) (1982-1984), XT600 (kickstart) (1982-1983), XT600 (electric start) (1984-1990), XT600 (electric start) (2001-2003), YFM600, YFM660 Raptor (2000-2001), YFM660 Raptor (2002-2007),
---------------	---

<b>Gas Gas</b>	EC200 (1997-2000), EC200 (2000 on), XC200 (1997 on), EC250 (1997-2000), EC250 (2000-2004), MC250 (1997-2004), XC250 (1997-2004), EC300 (1997-1999), EC300 (2000-2004), XC300 (1997-2004),
----------------	---

<b>KTM</b>	125SX (2000-2005), 125SX (2006-2010), 200SX, 250SX SEM Digitech (1985-1992), 400SX, 450SXF (2000-2005), 520SXF (2004-2005), 525SX (2004-2005), 625SXC/SMC, 640LC4 (1998 on), 640 Duke, 660SMC,
------------	--

## HT90

<b>Suzuki</b>	Suzuki GSX & GSXR models
---------------	--------------------------

## HT102

<b>Honda</b>	CB650/750/900,CBX1000, Kawasaki Z1000, Z1100
--------------	--